



41403 PLAYBACK

The Playback collection presents a clean, classic approach to home theatre seating. With simple lines, elegant topstitching, attached cushions and a foam-top storage arm, the Playback collection is an easy addition to any home theatre room. Semi-attached blown fibre back cushions create a pillow-like softness, while the full chaise seat offers support and exceptional comfort. The Playback collection is available in either power or manual recline, maximizing convenience. Plush seat and back cushions are pillow soft and will embrace you with warmth and comfort. The added convenience of built-in cupholders will keep your beverages safe. A multitude of straight, curved or combination configurations will suit any space and you can set up as many rows as needed to distinguish the lounging ambience for any occasion. As if these features were not enough, the Playback is compatible with a variety of accessories, all designed to enhance functionality and keep up with the demands of a highly functional space.

FEATURES

- **Frame Construction:** The majority of Palliser frames are constructed from engineered wood products, hardwood or softwood; joints are pinned and glued for uniformity and strength.
- **Mechanism Activation:** All armless manual pieces recline with D-pull activation handle, discreetly hidden between the arm and seat cushion., All armless power pieces recline with a discreet touch control button switch, located between the arm and the seat cushion., Power recline with a touch button switch, located on the LED cupholder when the LED option is selected, Manual recline with pull latch, finished in an attractive gunmetal gray, Power recline with a two button power toggle switch
- **Features:** Single top stitching for a clean and tailored finish (on leather and select fabrics), Hidden plastic glides integrated into the base
- **Cover:** All Palliser Fabrics, All Palliser Leathers
- **Cushions:** Semi-attached back cushions feature a fibre filling, blown into channels to prevent shifting and

FEATURE IMAGE (shown)
CONFIGURATION HD
5E LHF Power Recliner w/ RHF
Wedge Arm
7E RHF Wedge Arm Power Recliner
3E RHF Power Recliner



41403 PLAYBACK



PALLISER®
My Home, My Style, My Way™

- A. Seat Depth: 21.2 in / 53.9 cm
- B. Seat Height: 21.2 in / 53.8 cm
- C. Arm Height: 25.4 in / 64.4 cm
- D. Arm Depth: 34.6 in / 87.8 cm
- E. Seat Back Height: 22.8 in / 58.0 cm
- F. Width of Arm: 14.4 in / 36.5 cm
- G. Reclined Depth: 68.6 in / 174.3 cm
- H. Headrest Extension: N/A

Measurements displayed here represent the standard for this series. Some pieces may vary.



1R Recliner Manual
1E Recliner Power
39 x 39 x 42"
99 x 100 x 107cm
IA: 23" / 59cm



2R LHF Manual Recliner
2E LHF Power Recliner
31 x 39 x 42"
80 x 100 x 107cm



3R RHF Manual Recliner
3E RHF Power Recliner
31 x 39 x 42"
80 x 100 x 107cm



4R Armless Loveseat
Manual Recliner
4E Armless Loveseat Power
47 x 39 x 42"
120 x 100 x 107cm



5R LHF Manual Recliner w/
RHF Wedge Arm
5E LHF Power Recliner w/
45 x 39 x 42"
116 x 100 x 107cm
IA: 23" / 59cm



6R RHF Manual Recliner w/
LHF Wedge Arm
6E RHF Power Recliner w/L
45 x 39 x 42"
116 x 100 x 107cm
IA: 23" / 59cm



7R RHF Wedge Arm Manual
Recliner
7E RHF Wedge Arm Power
Re
38 x 39 x 42"
97 x 100 x 107cm



8R Armless Manual Recliner
8E Armless Power Recliner
24 x 39 x 42"
60 x 100 x 107cm




9R LHF Wedge Arm Manual
Recliner
9E LHF Wedge Arm Power
Re
38 x 39 x 42"
97 x 100 x 107cm


Dimensions are the same for reverse direction where applicable.

POPULAR CONFIGURATIONS


Note: Always assemble configurations from right hand facing to left hand facing. Dimensions are shown as width x depth.



HW 4 SEATS STRAIGHT
(1_/4_/1_)
124 x 68"
315 x 173 cm



HZ 4 SEATS CURVED
(5_/4_/6_)
136 x 71"
346 x 181 cm



Specifications are correct at time of printing and are subject to change without notice.

LHF = left hand facing means the "end arm" is on the LEFT HAND SIDE of the upholstered piece when you are standing in front of the piece.

RHF = right hand facing means the "end arm" is on the RIGHT HAND SIDE of the upholstered piece when you are standing in front of the piece.

Actual measurements for each item may vary from what is shown here. Please allow up to a +/- 1 inch difference.